



# System Scheme BoatSafeGuard



Free Web Service  
Configuration and Monitoring



Free App (All OS)  
Control/Switch and Monitoring



433 MHz Remote Control  
Switching



Internet



433 MHz

Installation Cable

External Cable